



1. Identification / recognition



The electric motor is silent. The indicator on the left of the instrument cluster (power meter) indicates whether the electric drive is switched "OFF" or "READY" for operation.








2. Immobilisation / stabilisation / lifting

Immobilize the vehicle

Apply the parking brake.

Lifting points



3. Disable direct hazards / safety regulations

Turn off the ignition (Powermeter "OFF")

Press the START-STOP button without depressing the brake pedal.



Instead of a radio key, it is also possible to use a key card or smartphone app.

Deactivate the high-voltage system




Option 1: From the engine compartment



Disconnect the 12-volt battery


Disconnect the negative pole from the body contact point.




Additionel information High-voltage disconnection point option 3 changed Document number rds_vwv_310_001_en **Version** 01/2021

Page 2 of 4









High-voltage disconnection point option 3 changed

rds_vwv_310_001_en

01/2021

⁴ of 4